

Xperia,GALAXY,iPhone

Brand	Model	Code	Status	Brand	Model	Code	Status	Brand	Model	Code	Status
Xperia	Xperia	(SO-01B)	S	Xperia	Xperia Z3	(SO-01G)	M	GALAXY	Galaxy A20	(SC-02M)	M
	Xperia 8 SOV42		L		Xperia Z3	(SOL26)	M		Galaxy A8 SCV32		L
	Xperia A	(SO-04E)	S		Xperia Z3 Compact	(SO-02G)	S		Galaxy Active neo	(SC-01H)	S
	Xperia A2	(SO-04F)	S		Xperia Z4	(SO-03G)	M		Galaxy Feel SC-04J		S
	Xperia A4	(SO-04G)	S		Xperia Z4	(SOV31)	M		Galaxy Feel2	(SC-02L)	M
	Xperia Ace	(SO-02L)	S		Xperia Z4	(402SO)	M		GALAXY J	(SC-02F)	S
	Xperia Ace SO-02L		S		Xperia Z5	(SO-01H)	M		GALAXY NEXUS	(SC-04D)	S
	Xperia acro	(SO-02C)	S		Xperia Z5	(SOV32)	M		GALAXY Note 3	(SC-01F)	L
	Xperia acro	(IS11S)	S		Xperia Z5	(501SO)	M		GALAXY Note 3	(SCL22)	L
	Xperia acro HD	(SO-03D)	S		Xperia Z5 (3社共通)	(SO-01H)	M		GALAXY Note Edge (docomo/au共通)	(SC-01G)	L
	Xperia acro HD	(IS12S)	S		Xperia Z5 Compact	(SO-02H)	S		GALAXY S	(SC-02B)	S
	Xperia arc	(SO-01C)	S		Xperia Z5 Compact SO-02H	(SO-02H)	S		GALAXY S II	(SC-02C)	S
	Xperia AX	(SO-01E)	S		Xperia Z5 Premium	(SO-03H)	L		GALAXY S II LTE	(SC-03D)	S
	Xperia GX	(SO-04D)	S		Xperia Z5 Premium SO-03H	(SO-03H)	L		GALAXY S II WiMAX	(ISW11SC)	S
	Xperia J1 Compact	(D5788)	S		Xperia ZL2	(SOL25)	S		GALAXY S III	(SC-06D)	S
	Xperia NX	(SO-02D)	S						GALAXY S III Progre	(SCL21)	S
	Xperia PLAY	(SO-01D)	S						GALAXY S III α	(SC-03E)	S
	Xperia ray	(SO-03C)	S						Galaxy S10	(SCV41)	M
	Xperia SX	(SO-05D)	S						Galaxy S10	(SC-03L)	M
	Xperia UL	(SOL22)	S						Galaxy S10+	(SC-04L)	L
	Xperia VL	(SOL21)	S						Galaxy S10+	(SC-05L)	L
	Xperia X Compact	(SO-02J)	S						Galaxy S10+	(SCV42)	L
	Xperia X Performance	(SOV33)	M						GALAXY S4	(SC-04E)	S
	Xperia X Performance	(502SO)	M						GALAXY S5	(SCL23)	M
	Xperia X Performance	(SO-04H)	M						GALAXY S5 (docomo/au共通)	(SC-04F)	M
	Xperia X Performance (3社共通)		M						GALAXY S5 Active	(SC-02G)	M
	Xperia XZ	(SO-01J)	M						Galaxy S6	(SC-05G)	M
	Xperia XZ	(SOV34)	M						Galaxy S6 edge	(SC-04G)	M
	Xperia XZ	(SOV34)	M						Galaxy S6 edge	(SCV31)	M
	Xperia XZ	(601SO)	M						Galaxy S6 edge (3社共通)	(SC-04G)	M
	Xperia XZ (3社共通)		M						Galaxy S6 SC-05G	(SC-05G)	M
	Xperia XZ Premium	(SO-04J)	L						GALAXY S7 edge (docomo/au共通)	(SC-02H)	L
	Xperia XZ1	(SO-01K)	M						GALAXY S7 edge	(SCV33)	L
	Xperia XZ1 Compact	(SO-02K)	S						Galaxy S8 SC-02J(docomo/au共通)	(SC-02J)	M
	Xperia XZ1(3社共通)		M						Galaxy S8 SC-02J		M
	Xperia XZ2	(SO-03K/SOV37)	L						Galaxy S8 SC-02J	(IS06)	M
	Xperia XZ2 Compact	(SO-05K)	S						Galaxy S9	(SC-02K)	M
	Xperia XZ2 Premium		L						Galaxy S9 SC-02K/SCV38	(SC-02K/SCV38)	L
	Xperia XZs (3社共通)	(SO-03J)	M						Galaxy S9+	(SC-03K/SCV39)	L
	Xperia XZs (3社共通)		M								
	Xperia Z	(SO-02E)	S								
	Xperia Z1	(SO-01F)	M								
Xperia Z1	(SOL23)	M									
Xperia Z1 f	(SO-02F)	S									
Xperia Z2	(SO-03F)	M									
Xperia Z3	(401SO)	M									
				iPhone	iPhone 4		S				
					iPhone 4S		S				
					iPhone 5		S				
					iPhone 5c		S				
					iPhone 5s		S				
					iPhone 6		S				
					iPhone 6 Plus		L				
					iPhone 6s		S				
					iPhone 6s Plus		L				
					iPhone SE		S				
					iPhone 7		S				
					iPhone 7 Plus		L				
					iPhone 8		S				
					iPhone 8 Plus		L				
					iPhone X		M				
					iPhone XS		M				
					iPhone XS Max		L				
					iPhone XR		L				
					iPhone 11		L				
					iPhone 11 Pro		M				
					iPhone 11 Pro Max		L				
					iPhone SE (第2世代)		S				

AQUOS,ARROWS

AQUOS	(SH-M02)	M		(SH-01F)	S	ARROWS A	(301F)	S
AQUOS Compact	(SH-02H)	S	AQUOS PHONE ZETA	(SH-06E)	S	ARROWS A	(202F)	S
AQUOS CRYSTAL	(305SH)	S		(SH-02E)	S	ARROWS A	(101F)	S
AQUOS CRYSTAL X	AQUOS CRYSTAL X	S		(SH-09D)	S	ARROWS A	(201F)	S
AQUOS CRYSTAL Y2		S		(SH-03J)	L	arrows Be F-04K		M
AQUOS CRYSTAL2	(403SH)	S	AQUOS R	(SHV39)	L	arrows Be F-04K F04K	F-04K	M
AQUOS ea		M		(604SH)	L	arrows Be F-05J		M
AQUOS EVER	(SH-02J)	M	AQUOS R (3社共通)		L	arrows Be F-05J		M
	(SH-04G)	S	AQUOS R compact		S	arrows Be3 F-02L		M
	(IS13SH)	S	AQUOS R2	(SH-03K)	L	ARROWS ef	(FJL21)	S
	(IS12SH)	S	AQUOS R2 compact		S	ARROWS ES	(IS12F)	S
	(006SH)	S	AQUOS R2	SHV42	L	arrows Fit	(F-01H)	S
	(104SH)	S		SH-04L	L	arrows Fit F-01H	F-01H	M
	(SH-06D)	S	AQUOS R3	SHV44	L	ARROWS Kiss	(F-03E)	S
	(SH-01D)	S	AQUOS sense	SH-01K	M	ARROWS kiss	(F-03D)	S
	(102SH)	S		SHV40	M	ARROWS M01	ARROWS M01	S
	(102SHII)	S	AQUOS sense2	SH-01L/SHV43	M	arrows M02	(M02)	S
	(SH-12C)	S		(SHV34)	M	arrows M03	M03	M
	(103SH)	S	AQUOS SERIE	SHV32	S	arrows M03/M02		M
	(IS11SH)	S		(SHL25)	S	arrows M04		M
	(IS14SH)	S		SHV38	S	ARROWS Me	(F-11D)	S
AQUOS PHONE CL	(IS17SH)	S	AQUOS SERIE mini	(SHV33)	S	arrows NX	(F-02H)	L
AQUOS PHONE es	(WX04SH)	S		(SHV31)	S	ARROWS NX	(F-04G)	M
AQUOS PHONE EX	(SH-04E)	S	AQUOS	(SH-M02)	S	ARROWS NX	(F-02G)	M
	(SH-02F)	S	AQUOS SH-M04		M	ARROWS NX	(F-01F)	S
AQUOS PHONE f	(SH-13C)	S	AQUOS U	SHV37	M	ARROWS NX	(F-05F)	S
	(SHL22)	M		SHV35	S	ARROWS NX	(F-06E)	S
	(SHL23)	S	AQUOS Xx	(404SH)	M	arrows NX F-01J		L
	(SHL21)	S		(304SH)	S	arrows NX F-01K		M
	(ISW16SH)	S	AQUOS Xx-Y 404SH		M	arrows NX F-02H	F-02H	L
AQUOS PHONE SERIE mini	(SHL24)	S	AQUOS Xx2		S	ARROWS S	(EM01F)	S
AQUOS PHONE si	(SH-07E)	S	AQUOS Xx2 mini	(503SH)	S	arrows SV	(F-03H)	M
	(SH-01E)	S	AQUOS Xx3	(506SH)	M	arrows SV F-03H		M
AQUOS PHONE SL	(IS15SH)	S	AQUOS Xx3 mini		S	arrows U		M
AQUOS PHONE slider	(SH-02D)	S		(SH-01G)	M	ARROWS V	(F-04E)	S
AQUOS PHONE ss	(205SH)	S		(SH-03G)	S	ARROWS X	(F-02E)	S
AQUOS PHONE st	(SH-07D)	S	AQUOS ZETA	(SH-01G)	S	ARROWS X	(F-10D)	S
AQUOS PHONE sv	(SH-10D)	S		(SH-04F)	S	ARROWS X LTE	(F-05D)	S
	(007SH)	S		(SH-01H)	S	ARROWS Z	(FJL22)	S
AQUOS PHONE THE HYBRID	(101SH)	S	AQUOS ZETA SH-04H		M	ARROWS Z	(ISW13F)	S
AQUOS PHONE THE PREMIUM	(009SH)	S				ARROWS Z	(ISW11F)	S
	(206SH)	S				ARROWS μ	(F-07D)	S
	(203SH)	S						
AQUOS PHONE Xx	(302SH)	S						
	(106SH)	S						
AQUOS PHONE Xx mini	(303SH)	S						

A~	102P		S	DIGNO S	(KYL21)	S	H~	HTC Desire	(X06HT)	S
	507SH Android One		M	DIGNO T	(302KC)	S		HTC Desire	(X06HTII)	S
	ALCATEL onetouch idol2		S	DIGNO U	DIGNOU	M		HTC Desire 626		M
	Alcatel IDOL 4		M	DIGNO V		M		HTC Desire EYE		L
	Alcatel One Touch Idol 3		L	DIGNO W		M		HTC Desire HD	(001HT)	S
	Android One S1		M	Disney Mobile on docomo	(DM-02H)	M		htc EVO 3D	(ISW12HT)	S
	Android One S2		M	Disney Mobile on docomo	(SH-02G)	S		htc EVO WiMAX	(ISW11HT)	S
	Android One S3		M	Disney Mobile on docomo	(SH-05F)	S		HTC J	(ISW13HT)	S
	Android One X1		L	Disney mobile on docomo	(N-03E)	S		HTC J butterfly	HTV31	L
	Ascend	G620S	M	Disney Mobile on docomo	(F-03F)	S		HTC J butterfly	(HTL23)	M
	Ascend	HW-01E	S	Disney Mobile on docomo	(F-07E)	S		HTC J butterfly	(HTL21)	M
	Ascend D2	HW-03E	S	Disney Mobile on docomo	(F-08D)	S		HTC J One	(HTL22)	S
	Ascend G6		S	Disney Mobile on docomo	(DM-01H)	S		HTC U11		L
	Ascend P7		S	Disney Mobile on docomo	(P-05D)	S		HTC U11	HTV33	L
	AXON 7		L	Disney mobile on docomo	(DM-01J)	M		HTC10	HTV32	M
	AXON 7 mini		M	Disney Mobile on docomo	DM-01K	M		HUAWEI Mate 10 Pro		L
	BASIO	(KYV32)	M	dynapocket	(T-01B)	S		HUAWEI Mate 20 lite		L
	BASIO 2	SHV36	M	ELUGA P	(P-03E)	S		HUAWEI nova 2	HWV31	M
	BASIO3	KYV43	M	ELUGA power	(P-07D)	S		HUAWEI nova 3		L
	BASIO3 KYV43	KYV43	M	ELUGA V	(P-06D)	S		HUAWEI nova lite 2		L
	BASIO4		L	ELUGA X	(P-02E)	S		HUAWEI P20 lite		M
	BlackBerry Bold 9700		S	EveryPhone BZ		L		HUAWEI P8lite	P8lite	M
	BlackBerry Bold 9780		S	EveryPhone PR		L		HUAWEI P9 lite PREMIUM		M
	BlackBerry Bold 9900		S	F-09D ANTEPRIMA		S		IDEOS		S
	BlackBerry Curve 9300		S	F-12C		S		INFOBAR	(A02)	S
	Blade E01	E01	M	FleaPhone CP-F03a		S		INFOBAR	(A03)	S
	BLADE Q+	BLADEQ+	S	FLEAZ F4s		S		INFOBAR	(C01)	S
	Blade V7 Max		L	FLEAZ F4s+		S		INFOBAR	(A01)	S
	BLADE V770		L	FLEAZ F5		S		IS02	IS02	S
	BLADE V770		M	Fx0		S		IS03	IS03	S
	Blade V7Max		L	G'zOne	(IS11CA)	S		IS05	IS05	S
	DELL Streak	(001DL)	L	G'zOne TYPE-L	(CAL21)	S		isai	(LGL22)	M
	DELL Streak Pro	(101DL)	S	g01 ZTE Blad L3		M		isai Beat	LGV34	M
	DELL Streak Pro	(GS01)	S	g02 ZTE Blad S Lite	g02	M		isai FL	(LGL24)	M
	DIGNO	(ISW11K)	S	G2	(L-01F)	S		isai vivid	LGV32	L
	DIGNO C	(404KC)	M	G2 mini		S		isai vivid LGV32	LGV32	M
	DIGNO C	(404KC)	M	GALAPAGOS	(005SH)	S		isai VL	(LGV31)	M
	DIGNO DUAL	(WX04K)	S	GALAPAGOS	(003SH)	S		KATANA 01		S
	DIGNO DUAL 2	(WX10K)	S	GS02		S		KATANA 02		M
	DIGNO E	(503KC)	M	GS03		S		Katana01	(FTJ152E-Katana01)	S
	DIGNO F		M	HONEY BEE	(201K)	S		Katana02	(FTJ152F-Katana02)	S
	DIGNO G		M	HONEY BEE	(101K)	S		KC-01	KC-01	S
	DIGNO J		M	honor 8		M		LG G3 Beat	LG G3 Beat	S
	DIGNO L		S	honor6 Plus		L		LG it	LGV36	M
	DIGNO M	(KYL22)	S	HTC 10	HTV32	M		LG style	(L-03K)	M
	DIGNO R	(202K)	S	HTC Aria	(S31HT)	S		LG style2 L-01L		L

Libero	{003Z}	S	Optimus it	{L-05D}	S	S301	{S301}	M	ZenFone 2	{ZenFone 2}	L
Libero2		M	Optimus LIFE	{L-02E}	S	samurai kiwami		L	ZenFone 2 Laser	{ZE500KL}	M
LINEAGE		M	Optimus LTE	{L-01D}	S	SAMURAI KIWAMI 2		L	ZenFone 3	{ZE520KL}	M
LUMIERE	{S03HW}	M	Optimus X	{I(S11G)}	S	SAMURAI REI		M	ZenFone 3 Deluxe	{ZE550KL}	L
LUMIX Phone	{P-02D}	S	P-01D	{P-01D}	S	SAMURAI REI [黒]		M	ZenFone 3 Laser	{ZE551KL}	M
LUMIX Phone	{101P}	S	P-04D	{P-04D}	S	SAMURAI T[黒]	{(FT1152C-Miyabi)}	M	ZenFone 4	{ZE554KL}	M
LYNX 3D	{SH-03C}	S	P-07C	{P-07C}	S	smart bar	{S42HW}	S	ZenFone 4 Pro	{ZE551KL}	L
meta 9		L	P10		M	Sony Ericsson mini	{S515E}	S	ZenFone 4 Selfie Pro	{ZD552KL}	L
Mate 10 Pro		L	P10 Lite		M	Spray	{402LG}	S	ZenFone 5		M
Mate 20 lite		L	P10 Plus		L	STAR7	{009Z}	S	ZenFone 5	{ZE620KL}	L
Mate 20 Pro		L	P20 lite		L	StarQ	{Q5001}	M	ZenFone AR		L
Mate 9		L	P20 lite	{HWV32}	M	STREAM	{201HW}	S	ZenFone AR ZS571LK		L
MEDIAS	{N-04C}	S	P20 Pro	{HW-01K}	S	STREAM S	{S02HW}	S	ZenFone Go		L
MEDIAS BR	{S11N}	S	P20 Pro		S	STREAM X	{GLO7S}	S	ZenFone Live	{ZB501KL}	M
MEDIAS CH	{101N}	S	P30 lite Premium	{HWV33}	L	Sweety	{003P}	S	ZenFone Live (L1)	{ZA550KL}	L
MEDIAS ES	{N-05D}	S	P9 lite		M	TO NE	{m15}	M	ZenFone Max		L
MEDIAS LTE	{N-04D}	S	P9 lite PREMIUM		M	TORQUE		S	ZenFone Max Pro (M1) ZB602KL		L
MEDIAS PP	{N-01D}	S	PadFone 2	{PadFone 2}	S	TORQUE G03		M	ZenFone Zoom S ZE553KL		L
MEDIAS U	{N-02E}	S	Panda	{3rd Lot}	L	TORQUE (トルク) SKT01		S	ZTE Blade V580	{V580}	L
MEDIAS W	{N-05E}	S	PANTONE 5	{107SH}	S	ufone	{007}	M	かんたんスマホ	{705KC}	M
MEDIAS WP	{N-06C}	S	PANTONE 6	{200SH}	S	UPO Phone A01X		S	シンプルスマートフォン	{008Z}	S
MEDIAS X	{N-06E}	S	Pocket WiFi S	{S31HW}	S	URBANO	{V02}	M	シンプルスマホ	{204SH}	S
MEDIAS X	{N-07D}	S	Pocket WiFi S II	{S41HW}	S	URBANO	{V01}	S	シンプルスマホ2	{401SH}	S
MIRACH	{S11PT}	S	PRADA phone by LG	{L-02D}	S	URBANO	{L03}	S	シンプルスマホ3		M
mirale	{KYL23}	S	priori		S	URBANO	{L01}	S	シンプルスマホ4		M
mirale f	{KYV39}	S	Priori 3S LTE	{FTJ152B}	M	URBANO	{L02}	S	スマートフォン for ジュニア	{SH-05E}	M
MONO	{MO-01J}	S	Priori 4		M	URBANO PROGRESSO		S	スマートフォン for ジュニア2	{SH-03F}	S
MONO MO-01K		M	Priori 5	{FTJ17C0D}	S	URBANO V03		M	らくらくスマートフォン	{F-12D}	S
MOTOROLA PHOTON	{(SW11M)}	S	priori2		S	V20 PRO	{L-01J}	M	らくらくスマートフォン me	{F-03K}	S
MOTOROLA RAZR	{S12M}	S	Priori3 LTE	{FTJ152A}	S	V30+	{L-01K}	L	らくらくスマートフォン プレミアム	{F-09E}	S
Nexus 4		S	Priori3S LTE	{FTJ152B}	M	V30+ L-01K LGV35	{L-01K}	L	らくらくスマートフォン2	{F-09E}	S
Nexus 5	{Nexus 5}	S	Q-pot Phone	{SH-04D}	S	V30+ L-01K LGV35	{L-01K/LGV35}	L	らくらくスマートフォン3	{F-06F}	S
Nexus 5X	{(docomo/Ymobile共通)}	M	Qua phone	{KYV37}	M	VAIO Phone	{VA-10J}	M	らくらくスマートフォン4 F-04J		S
nico		M	Qua phone PX		M	VEGA	{PTL21}	S	らくらくスマートフォン me	{F-01L}	M
nova		M	Qua phone qx		M	Vision	{007HW}	S			
nova 2	{HWV31}	M	rafre f	{KYV39}	S	Windows Phone	{IS12T}	S			
nova 3		L	rafre KYV40		M	XM		M			
nova lite		M	RAIJIN		M						
nova lite 2		L	RAZR M	{201M}	S						
Optimus bright	{L-07C}	S	REGZA Phone	{T-02D}	S						
Optimus chat	{L-04C}	S	REGZA Phone	{T-01D}	S						
Optimus G	{L-01E}	S	REGZA Phone	{I(S11T)}	S						
Optimus G	{L-GL21}	S	REGZA Phone	{T-01C}	S						
Optimus G pro	{L-04E}	S	REGZA Phone	{IS04}	S						
Optimus it	{L-05E}	S	REI 2 Dual	{(FTJ17A0D)}	L						